

The logo for ARITECH, featuring the word "ARITECH" in a bold, blue, sans-serif font with a stylized arrow pointing to the right.

ADVISOR
MASTER[®]
TOTAL SECURITY SYSTEM

→ **ATS Control Panel**

User's Manual

ARITECH is a division of GE Interlogix BV

COPYRIGHT

© 2004 GE Interlogix BV. All rights reserved.

GE Interlogix BV grants the right to reprint this manual for internal use only.

GE Interlogix BV reserves the right to change information without notice.

TABLE OF CONTENTS

Welcome	3
Looking at the keypad	4
Using your PIN code to access the system	5
Accessing the menu options	6
To access the menu options	7
Arming the system	8
To arm the system	9
Disarming the system	10
To disarm the system	10
Inhibiting a zone	12
To inhibit a zone	12
Uninhibiting a zone	14
To uninhibit a zone	15
What to do when there is an alarm	16
To reset a local alarm	17
To disarm an area in alarm	19
Listing recent alarms	20
To list recent alarms events	21
Glossary	22
Index	23

WELCOME

This manual explains how to use the alarm system for every day use. It is applicable for all ATS control panels (ATS2000/3000/4000 series). Please read these instructions carefully before you start using the system for the first time, and keep them in a safe place for easy reference.

Symbols are used in this manual to help explain the information:



Note. Gives you extra information.





Press a button on the keypad.



The alphanumeric buttons on the keypad.

LOOKING AT THE KEYPAD



1 System LEDs

Used to display system main power, system faults and alarm.

2 Area LEDs

Used to display which areas are armed or in alarm.

3 CLEAR button

Used to exit the current function.

4 Alphanumeric buttons

Used to enter information and codes.

5 MENU* button

Used to:

- display the menu login prompt.
- backspace to correct an error.
- scroll backwards in the menu.

6 ENTER button

Used to:

- complete a step.
- scroll forward in the menu.

7 OFF button

Used after entering your PIN code to disarm the system.

8 ON / NEXT button

NEXT button

Used to:

- display the next item in a menu list.
- update the information displayed.

ON button

Used after entering your PIN code to arm the system.

9 LCD Display

Used to display messages

10 ON button (ATS1110/1111)

Used after entering your PIN code to arm the system.

11 Left/Right button

For future use.

Continued overleaf...

USING YOUR PIN CODE TO ACCESS THE SYSTEM

You need a PIN code and/or a card to use the Advisor **MASTER** system. Your PIN code has between four and ten digits and is unique for each user.

The manager of the security system has programmed your PIN code so that it lets you do specific tasks, such as arming or disarming the system. You can only access the menu options that your PIN code had been authorised to access. When you try to access an option that you are not authorised to access, you get the message *You are unauthorised for this function.*

Also, although you may be able to access a menu option, depending on how your PIN code has been programmed, you may not be authorised to access all the information available on it.

If you access the menu and do not use any keys for two minutes, you will automatically exit from the menu. It is a good practice to exit the menu using the CLEAR button rather than the time out facility because if someone else uses the menu before it times out, the functions used can be logged against your PIN code.

12 OPEN button

Used to: - open a door via a valid code (if programmed)

13 For future use

14 Up/Down buttons

Up button


Used to: - scroll up the menu list
- update the information displayed.

Down button

Used to: - scroll down the menu list
- update the information displayed.

ACCESSING THE MENU OPTIONS

The Advisor **MASTER** system lets you carry out several different functions. These functions are accessed through the menu options. The instructions on the right show you how to move between the different menu options available.

 *You can only access the menu options that are authorised for your PIN code.*

See page 5, *Using your PIN code*, for further information.

Start with this display message with the Code prompt on the bottom line. ●●●●●●●●●●

Press the **MENU*** button ●●●●●●●●●●

The new message is displayed. ●●●●●●●●●●

Enter your **PIN** code ●●●●●●●●●●

Press the **ENTER** button ●●●●●●●●●●

The new message is now displayed. ●●●●●●●●●●

Scroll – lets you scroll through the menu options one by one.

Press **ENTER** button to scroll forward

Press **MENU*** button to scroll backwards


Then enter the menu number of the menu you want to access. Press **ENTER**.

Jump – lets you jump to a specific menu option. Enter the menu number and press **ENTER**. ●●●●●●●●●●

Exit – Lets you exit and return to the original display shown at the top of the page.

Press **CLEAR** or **0** button to exit automatically. ●●●●●●●●●●

TO ACCESS THE MENU OPTIONS



ARMING THE SYSTEM

When to arm:

You arm the premises, or an area in it, when it is unoccupied, for example at the end of the day when everyone has gone home. Then if an unwanted event occurs, such as someone forcing open a door, this sets off an alarm.

The time limit to leave the premises once armed:

Once you have armed the system, you must leave the premises (or area) within a pre-set time as otherwise you will set off the alarm. The manager of your system will inform you what this time limit is.

Normally, you will hear a beeper during the time allowed to leave the building.

When you cannot arm or disarm:

You might not be authorised to arm/disarm specific areas in the premises because:

- Your PIN code has been programmed to arm/disarm only specific areas in the premises. Make sure you know which areas you are authorised to arm/disarm.
- Your alarm system might have more than one control panel. If so, each will have been programmed to arm/disarm only specific areas in the premises. Make sure you use the correct keypad for the areas you want to arm/disarm.
- You cannot arm an area if it has a zone that is open, such as the magnetic contacts of a door or window. So, before arming, make sure that all doors and windows are properly closed.

If a zone is open when you try to arm, the keypad will beep quickly seven times and you will get the message "Active on ...". You must then fix the problem.

The manager of your system will tell you which keypad(s) you can use and which area(s) you can arm/disarm.

Start with this message.

The Code line is the bottom line. ●●●●●●●●●●
The LED of the area you want to arm is off.

Enter your **PIN** code ●●●●●●●●●●

Press **ON** ●●●●●●●●●●

What happens next depends on how your PIN code has been programmed: ●●●●●●●●●●

PIN code not programmed to display areas

After entering the code and pressing **ENTER**, all disarmed areas are automatically armed and the display returns to the beginning.

PIN code programmed to display areas


You can do one of three options:

1. **Display more areas** – lets you display the next disarmed area in the list. Select the area you want to arm as explained below (option 3) or press **NEXT** again. When finished, press **ENTER**. ●●●●●
2. **Arm all areas** - lets you arm all the areas at once. Press the **0** button and then **ENTER**. ●●●●●
3. **Arm individual areas**- lets you arm selected area(s) one at a time. Enter the area number and press **ENTER** for each area you want to arm. ●●●●●

When finished, press **ENTER** again. ●●●●●●●●●●

When an area is armed, its LED lights up red.

TO ARM THE SYSTEM



TO DISARM THE SYSTEM

THERE ARE NO ALARMS IN THIS AREA
CODE :

 **PIN code**

OFF

OR

PIN code programmed to display areas

All disarmed areas are listed in the display. For example :

0-ALL, OFFICE 2, BOARDROOM 3
ENTER AREA :

PIN code not programmed to display areas

THERE ARE NO ALARMS IN THIS AREA
CODE :

To display more areas

NEXT

To disarm all areas

0

ENTER

To disarm individual areas

 Zone N°

ENTER

ENTER

THERE ARE NO ALARMS IN THIS AREA
CODE :

INHIBITING A ZONE

This function is used to inhibit zones and exclude them from the security system. You do this, for example, when a zone is faulty or broken. By inhibiting it, you stop it causing an alarm until it is fixed.

There may also be occasions when you want to inhibit a normal zone. For example, if you want to leave a window open when the system is armed. By inhibiting the zone associated with the window, when you arm the system you will not set the alarm.

Start with the Code line on the bottom line of the display.

Press the **MENU*** button.

Enter your **PIN Code**.

Press **ENTER**.
(See page 6 for more information on accessing menu options)

Press **10** and **ENTER**.

What happens next depends on whether or not there are inhibited zones:

All zones are normal- You can inhibit normal zones if you know their zone number.

Enter the **zone number** and press **ENTER** to inhibit the zone, or press **CLEAR** to exit programming.

Active zones - There are one or more zones active. These zones are listed either:

- one by one, or
- as a list of numbers

When the zones are listed one by one, to scroll use the **NEXT** button

Depending on the state of the zones you can:

- **Inhibit the active zone**

Enter the **Zone N°** and then press **ENTER**.
When finished, press **ENTER** and **CLEAR** to exit programming.

- **Inhibit the normal zone**

Enter the **Zone N°** and then press **ENTER**.
When finished, press **ENTER** and **CLEAR** to exit programming.

- **Exit** - lets you exit programming.
Press **CLEAR**.

TO INHIBIT A ZONE

THERE ARE NO ALARMS IN THIS AREA
CODE :

MENU



PIN Code

ENTER

10

ENTER

To scroll

NEXT

Active zones

Active zones are listed either :

ACTIVE ON 4. PIR IN MANAGERS OFFICE
INHIBIT:

OR

ACTIVE ON 1, 4, 6
INHIBIT:

Normal zones

The display shows :

ALL ZONES ARE NORMAL
INHIBIT:

To inhibit
a zone

Zone N°

ENTER

ENTER

CLEAR

INHIBITED ZONES IN THIS AREA
CODE :

UNINHIBITING A ZONE

This function is used to uninhibit zones and include them into normal operation.

Start with the Code line on the bottom line of the display.

Press the **MENU*** button.

Enter your **PIN code**.

Press **ENTER** (see page 6 for more information on accessing menu options).

Press **11** and **ENTER**.

What happens next depends on whether or not there are inhibited zones:

No inhibited zones - Press **CLEAR** to exit programming.

Inhibited zones - There are one or more inhibited zones. These zones are listed either:
- one by one, or
- as a list of numbers.
When the zones are listed one by one, to scroll use the **NEXT** button.

Depending on the state of the zone, you can now:

- **Uninhibit the inhibited zone** - lets you uninhibit the selected zones. Press the **Zone N°** and then **ENTER**. When finished, press **ENTER** to return to the beginning.
- **Exit** - lets you exit programming. Press **CLEAR**.

TO UNINHIBIT A ZONE

INHIBITED ZONES IN THIS AREA
CODE :

MENU*

 **PIN Code**

ENTER

11

ENTER

To scroll

NEXT

Inhibited zones

Inhibited zones are listed either :

INHIBITED ON 4. BEAM ACROSS LOADING BAY
UNINHIBIT:

OR

INHIBITED ON 1, 4, 6
UNINHIBIT:

No inhibited zones

The display shows :

ALL ZONES ARE UNINHIBITED
UNINHIBIT:

To uninhibit
a zone

Zone N°


ENTER

ENTER

CLEAR

THERE ARE NO ALARMS IN THIS AREA
CODE :

TO RESET A LOCAL ALARM



WHAT TO DO WHEN THERE IS AN ALARM (continued)

- **System alarm** - This alarm can occur at any time. The exact type of alarm signal depends on how the system has been programmed (flashing lights, sirens,...).

It occurs when the security equipment (such as the panel) has been tampered with, or detects a fault.

You can only reset a system alarm if your PIN code has been authorised to do so.

When programmed, the central station is contacted automatically by the system.

Who to contact when an alarm occurs:

Contact the manager of your security system when an alarm occurs.

Problems that can occur:

- **There is a faulty zone** - This will continue to cause an alarm until it is inhibited from the system (see page 10).

As soon as you inhibit the faulty zone, the alarm is reset automatically.

- **Your PIN code does not work when you try to reset an alarm**- there are two possible reasons:

- You can only reset an alarm for an area if your PIN code is assigned to it. If it is not and you try to reset an alarm, you might arm/disarm the area instead.

- You cannot reset a system alarm unless your PIN code is authorised to do so.

An area LED on the panel flashes to show in which area the alarm is located. ●●●●●

Enter your **PIN code**. ●●●●●●●●●●●●●●●●●●●●●●●●

Press **OFF**. ●●●●●●●●●●●●●●●●●●●●●●●●

What happens next depends on how your PIN code has been programmed:

PIN code not programmed to display areas ●●●●●

All programmed armed areas are disarmed automatically.

PIN code programmed to display areas


You can do one of four options:

- 1. **Display more areas** – lets you display the next armed area in the list. Select the area you want to disarm as explained below (option 3) or press **NEXT** again. When finished, press **ENTER**. ●●
- 2. **Disarm all areas** - lets you disarm all areas at once. Press the **0** button and then **ENTER**. ●●●●
- 3. **Disarm individual areas**- lets you disarm selected area(s) one at a time. Enter the area number and press **ENTER** for each area you want to disarm. When finished, press **ENTER** again. ●●
- 4. **Exit** – Press **CLEAR**. Areas stay armed.

The LED stops flashing. The area is now disarmed.

Fix the problem (e.g. close the door) ●●●●●

TO DISARM AN AREA IN ALARM



LISTING RECENT ALARMS

This is a quick and easy way to review where and when alarms have happened. This information is useful when you have had to reset an alarm without initially checking its cause.

If there is an alarm condition when you request the list, then only information about that alarm is shown.

WHEN THERE ARE NO ALARMS:

Press the **ENTER** button twice to get the recent alarms information

The display shows where the alarm is occurring.

You can now:

- **Scan recent alarms.** Press **1**.
- **Exit history.** Lets you exit the alarm history and return to the initial display. Press **0**.

WHEN THERE IS AN ALARM:

Press the **ENTER** button twice to get the recent alarms information

The display shows where the alarm is occurring.

You can now:

- **Scroll forward in the list.** Press **NEXT**.
- **Exit.** Lets you exit the alarm history and return to the initial display. Press **ENTER**.

TO LIST RECENT ALARMS EVENTS

WHEN THERE ARE NO ALARMS

THERE ARE NO ALARMS IN THIS AREA
CODE :



ENTER



ENTER

13:23 - 31/10 - LOCAL ALARM Zone 1
1-Scan, Ø Exit :

OR

To scan recent
alarms



1

To exit list of
recent alarms



0

THERE ARE NO ALARMS IN THIS AREA
CODE :

WHEN THERE IS AN ALARM

CODE :



ENTER



ENTER

ALARM ON T3
NEXT OR ENTER

OR

To scroll
forwards



NEXT

To exit



ENTER

CODE :

GLOSSARY

Active zone (open)	The device on the zone is activated, for example the door is opened.
Area	The section of a premises with its own security requirements. There can be several areas in a premises, such as the meeting room, office, and store room.
Armed	The security system is switched on.
Central station	A security company that monitors whether an alarm has occurred. It is located away from the premises/areas it monitors.
Control panel	This is the “brain” of the system. It monitors all zones and determines how they will respond.
Disarmed	The security system is switched off. The tamper, duress, hold up, panic and fire zones are still operational.
History	A list of recent alarm events that are stored in memory. It is displayed on the LCD display of the keypad.
Inhibit	The zone is temporarily disconnected from part of the security system.
LCD	The messages are displayed on the Liquid Crystal Display of the keypad connected to the control panel.
LED	A Light Emitting Diode is a light on the control panel that indicates a condition, such as normal status or an alarm. It is green (normal), orange (fault), or red (armed/alarm) depending on the condition.
Normal zone (closed)	The device on the zone is not activated, for example the door is closed.
PIN code	The Personnel Identification Number that lets you arm and disarm the system as well as giving access to other functions (if allowed). It is a 4 to 10 digit number used to enter the security system via the keypad before most functions can be carried out. Each user has a unique PIN code.
PIR device	Passive infra red motion detection unit.
Tamper	A tamper is a safeguard against the zones or control panel being interfered with or broken, such as a cable being cut. When such a situation is detected, an alarm is activated.
Zone	A zone is connected to devices, such as a magnetic contact or PIR device, that can generate an alarm. Each zone has its own number and associated name, such as: 6 Entrance.

A

- Accessing menu options 6
- Acknowledging a local alarm 16
- Alarm history
 - getting a list of recent alarms 20
- Alarms
 - acknowledging 16
 - definition 16
 - disarming input in alarm 19
 - Listing present alarms 20
 - local alarm 16
 - PIN code does not work 18
 - resetting 19
 - who to contact when an alarm occurs 18
- Arming
 - depends on how PIN code is programmed 8
 - displaying the disarmed areas 8
 - pre-set time to leave 8
 - situations when you cannot arm/disarm 8
 - when to arm 8

D

- Description of symbols used in manual 3
- Disarming
 - depends on how PIN code is programmed 10, 18
 - displaying the armed areas 10, 18
 - input when in alarm 19
 - pre-set time to enter 10
 - situations when you cannot disarm 10
 - when to disarm 10

E

- Exiting from menu option
 - using keypad or time out facility 5

G

- Getting a list of past alarm events 20
- Glossary of terms 22

I

- Inhibiting zones
 - leaving the window open when arming the system 12

K

- Keypad
 - description 4
 - using specific one when arming/disarming 8

L

- LED
 - red 8
 - unlit 10
- Listing recent alarms 20
- Local alarm
 - acknowledging 17
 - definition 16
 - resetting 17

M

- Menu options
 - accessing them 6
 - exiting using keypad or time out facility 5
 - jumping to a specific menu option 6
 - scrolling through them 6
- Messages
 - Local Alarm 16
 - You are unauthorised for this function 5

P

- PIN code
 - restrictions using it 5
 - using it 5
- PIN code does not work
 - when arming/disarming 8
 - when resetting alarm 18
 - when trying to access menu option 5

Q

- Quick alarm history
 - use after disarming 10

R

- Recent alarms
 - listing 20
- Resetting an alarm 18

S

- Symbols used in this manual 3
- System alarm 18

U

- Uninhibiting zones 14
 - cancel command 14

Z

- Zones
 - Active 12
 - disarming when in alarm 18
 - faulty/broken 12
 - inhibiting 12
 - normal 12
 - uninhibiting 14

